

# Speco's Best Practices Install Checklist



- Set up username, password, and document credentials
- Go through the EZ Wizard setup
- Verify firmware is updated, if not update.  
([Specotech.com](http://Specotech.com) - [Support](#) - [Recorder Software Updates](#))
- Verify recorder is online with a “success” on the NAT 2.0 page
- Name Cameras under “Camera”
- Set Motion Recording area on every camera
- Set “Event Recording” Frames per second, 15fps recommended  
([Settings](#) - [Record](#) - [Event Record Setting](#))
- Set “Scheduled Recording” Frames per second, 15fps recommended  
([Settings](#) - [Record](#) - [Scheduled Recording Settings](#))
- Record Substream Frames per second, 8-12fps recommended  
([Settings](#) - [Record](#) - [Record Substream](#))
- “Network Stream Settings”, 8-12fps recommended  
([Settings](#) - [Network](#) - [Network Stream Settings](#))
- Set up SMTP server if using “email” notifications
- Demo Playback/Search and Export/  
Analytic Analysis to customer from recorder
- Download App to Customer’s phone(s)  
([Settings](#) - [Network](#) - [NAT](#) - “No Client Yet? Click to Download”)
- Demo App to Customer  
([Specotech.com](http://Specotech.com) - [Learning Center](#) - [Quick Hits](#) - [Speco Blue](#))
- Log Recorder information, QR Code, username and password  
([Settings](#) - [Network](#) - [NAT](#))



---

## When utilizing analytics, review these steps:

- Set Line Crossing/Intrusion for People/Vehicle Detection  
([Settings](#) - [AI/Event](#) - [People/Vehicle Detection](#))
- Set Facial Detection/Recognition  
([Settings](#) - [AFI Event](#) - [Face Recognition](#))
- Set LPR Detection for License Plate Recognition  
([Settings](#) - [AFI Event](#) - [LPR](#))

---

## Optional steps:

- Download SecureGuard CMS, Speco Blue VMS, (Connect.specotech.cloud, or local IP login) Using web browser
- Demo Speco Software and/or remote login to customer